

AC NO: 43.13-2A

DATE: Revised 1977



ADVISORY CIRCULAR

DEPARTMENT OF TRANSPORTATION FEDERAL AVIATION ADMINISTRATION

SUBJECT: ACCEPTABLE METHODS, TECHNIQUES, AND PRACTICES—
AIRCRAFT ALTERATIONS

1. PURPOSE.

This advisory circular contains methods, techniques, and practices acceptable to the Administrator for use in altering civil aircraft.

2. CANCELLATION.

Advisory Circular 43.13-2 dated 1965 is cancelled.

3. REFERENCE.

Part 43 of the Federal Aviation Regulations requires that methods, techniques, and practices

acceptable to the Administrator must be used when altering civil aircraft. Methods, techniques, and practices other than those prescribed in this advisory circular may be used provided they are acceptable to the Administrator. FAA Inspectors are prepared to answer questions that may arise in this regard. Persons engaged in alteration of civil aircraft should be familiar with FAR Part 43, and subparts A, D, and E of FAR Part 65, and the applicable airworthiness requirements under which the aircraft was type certificated.


J. A. FERRARESE

Acting Director, Flight Standards Service

CONTENTS

Chapter 1. STRUCTURAL DATA

<i>Paragraph</i>	<i>Page</i>
1. General	1
2. Static Loads	1
3. Static Tests	1
4. Materials	2
5. Fabrication	2
6. Fasteners	2
7. Protection Against Deterioration	2
8. Provisions for Inspection	2
9. Effects on Weight and Balance	2
10. Effects on Safe Operation	2
11. Controls and Indicators	2
12. Placarding	2
13.-20. [Reserved]	2

Chapter 2. RADIO INSTALLATIONS

21. Installation	5
22. Equipment Manufacturer's Instructions	5
23. Instrument Panel Mounting	5
24. Other Mounting Areas	6
25. Fabrication of Supporting Brackets for Attachment to Structure Other Than Flooring	7
26. Supporting Structure Reinforcement	7
27. Electrical Systems	9
28. Emergency Locator Transmitter (ELT) Installations	12
29.-35. [Reserved]	12

Chapter 3. ANTENNA INSTALLATIONS

36. Performance	13
37. VHF Antenna—Whip	13
38. VHF Antenna—Rigid	14
39. VHF Navigation Receiving Antennas	15
40. Range Receiving Antennas	19
41. Marker Receiving Antenna	19
42. ATC Radar Beacon (Transponder) and Distance Measuring Equipment (DME) Antennas	19
43. Direction Finding Antennas	20
44. Antenna Installation on Pressurized Aircraft	21
45.-50. [Reserved]	24

Chapter 4. ANTICOLLISION AND SUPPLEMENTARY LIGHT INSTALLATIONS

51. Anticollision and Supplementary Light Systems	25
52. Interference	25
53. Markings and Placards	25
54. Electrical Installation	26
55. Alteration of Structure	26
56. Guidelines for Installations	27
57.-60. [Reserved]	31

CONTENTS—Continued**Chapter 5. SKI INSTALLATIONS**

<i>Paragraph</i>	Section 1. SELECTION OF SKIS	<i>Page</i>
61. Determining Eligibility of Aircraft		33
62. Identification of Approved Model Skis		33
63. Maximum Limit Load Rating		33
64. Landing Gear Moment Reactions		34
65. [Reserved]		34
	Section 2. CONVERSION AND INSTALLATION	
66. Hub-Axle Clearance		35
67. Crust-Cutter Cables		35
68. Cable and Shock Cord Attachment and Attachment Fittings		35
69. Provisions for Inspection		36
70. [Reserved]		36
	Section 3. RIGGING OF SKIS	
71. Location of Attach Fittings on Fuselage or Landing Gear		37
72. Main Ski Incidence Angles		37
73. Tension Required in Main Ski Shock Cords		37
74. Nose Ski Installation		38
75. Tail Ski Installation		38
76.-78. [Reserved]		40
	Section 4. OPERATION	
79. Performance Information		41
80. Flight and Handling Operational Checks		41
81. Interchanging of Skis and Wheels		41
82.-85. [Reserved]		41

Chapter 6. OXYGEN SYSTEM INSTALLATIONS IN NONPRESSURIZED AIRCRAFT

86. System Requirements	43
87. Installation	43
88. Location and Mounting	44
89. Thread Compound	45
90. Functional Test	45
91. Operating Instructions	46
92.-95. [Reserved]	47

Chapter 7. ROTORCRAFT EXTERNAL-LOAD DEVICE INSTALLATIONS

	Section 1. CARGO SLINGS	
96. General		49
97. Quick-Release Device		49
98. Location of Cargo Release in Relation to the Rotorcraft's C. G. Limits		49
99. Maximum External Load		50
100. Static Test		50
101. Sling-Leg Angles of Cable-Supported Slings		50
102. Minimum Sling-Leg Cable Strength		50
103. Sling Installation		50
104. Installation of Release Controls		51
105. Functional Test		52
106. Supplemental Flight Information		52
107.-110. [Reserved]		53
	Section 2. CARGO RACKS	
111. General		54
112. Fabrication of Cargo Racks		54
113. Static Test		54
114. Supplemental Flight Information		54
115.-120. [Reserved]		55

CONTENTS—Continued

Chapter 8. GLIDER AND BANNER TOW-HITCH INSTALLATIONS

<i>Paragraph</i>	Section 1. TOWPLANE CONSIDERATIONS	<i>Page</i>
* 121.—125.	Deleted Change 1	57
	Section 2. TOW-HITCH INSTALLATIONS	
126.	Structural Requirements	58
127.	Structural Testing	59
128.	Attachment Points	59
129.	Angles of Tow	59
130.	Placards	59
131.	Weight and Balance	59
132.	Tow Release Mechanism	59
* 133.	Deleted Change 1	60
134.—145	[Reserved]	63

Chapter 9. SHOULDER HARNESS INSTALLATIONS

	Section 1. RESTRAINT SYSTEMS	
146.	General	65
147.	Types of Restraint Systems	65
148.	Advantages of Different Harness Types	65
149.	Mounting Configurations	65
150.	Standards	65
151.	Materials	65
152.—155.	[Reserved]	66
	Section 2. EFFECTIVE RESTRAINT ANGLES	
156.	Relationship of the Harness Assembly to the Occupant	67
157.	Attachment Areas for Shoulder Harness	67
158.	Area and Angle Deviations	68
159.—160.	[Reserved]	70
	Section 3. ATTACHMENT METHODS	
161.	Structural Attachments	71
162.	Floor and Seat Attachments	71
163.	Airframe Attachments	72
164.	Structural Repair Kits	72
165.	Flexible Attachments	72
166.	Simplified Installation Criteria	74
167.	Engineering Approval	74
168.—175.	[Reserved]	75

Chapter 10. BATTERY INSTALLATIONS

	Section 1. GENERAL	
176.	General	77
177.	Location Requirements	77
178.	Duplication of the Manufacturer's Installation	78
179.	Other Installations	78
180.—185.	[Reserved]	78
	Section 2. INSTALLATION	
186.	Securing the Battery	79
187.	Venting	79
188.	Drains	79
189.	Electrical Installation	80
190.—195.	[Reserved]	80

CONTENTS—Continued

<i>Paragraph</i>	<i>Page</i>
Section 3. REPLACEMENT OF LEAD-ACID BATTERIES WITH NICKEL-CADMIUM BATTERIES	
196. General	81
197. Electrical Analysis	81
198. Maintenance Considerations	81
199. Structural Requirements	81
200. Isolation of Battery Case	81
201. Ventilation	82
202. Preinstallation Requirements	82
203. Securing The Battery	83
204. Voltage and Current Regulation	83
205. Weight and Balance	83
206. Restoration of Lead-Acid Batteries	83
207.-210. [Reserved]	83
 Chapter 11. ADDING OR RELOCATING INSTRUMENTS	
211. General	85
212. Preparation	85
213. Installation	85
214. Testing, Marking and Placarding	88
215.-240. [Reserved]	88
 Chapter 12. LITTER, BERTH, AND CARGO TIEDOWN DEVICE INSTALLATIONS	
241. General	89
242. Installation Considerations	89
243. Fabrication and Installation	89
244. Structural Attachment	89
245. Load Factors	95
246. Static Tests	95
247. Operating Limitations, Loading Instructions, and Placards	96
248.-260. [Reserved]	96
 Chapter 13. PENETRATION THROUGH PRESSURIZED STRUCTURE	
Section 1. ELECTRICAL WIRE BUNDLES AND COAXIAL CABLE FEED THROUGH PRESSURIZED STRUCTURE	
261. General	97
262. Cleaning	97
263. Application of Sealant	97
264.-290. [Reserved]	97

LIST OF ILLUSTRATIONS

<i>Figure</i>	<i>Page</i>
1.1 Hypothetical Example of Determining Static Test Loads	3
2.1 Typical Radio Installations in Stationary Instrument Panels	6
2.2 Typical Panel Mount	6
2.3 Typical Shockmounted Base	6
2.4 Typical Shockmounted Base	7
2.5 Typical Rigid Baseplate Mount	7
2.6 Typical Underseat Installation	7
2.7 Typical Remote Unit Mounting Base-Vertical or Horizontal	8
2.8 Typical Shelf Installation	9
2.9 Typical Rail Platform Installation—Aluminum Alloy Structure	9
2.10 Typical Attachment of Support Structure to Tubular Frame	10
2.11 Typical Mounting Plates for Remote Location of Radio Units	11
3.1 Typical Whip Antenna Installation	13

CONTENTS—Continued**LIST OF ILLUSTRATIONS—Continued**

<i>Figure</i>		<i>Page</i>
3.2	Antenna Ground Plane for Nonmetallic Aircraft	14
3.3	Typical Shockmounted Antenna Installation	14
3.4	Typical Rigid Antennas	15
3.5	Typical Antenna Mounting Template	15
3.6	Typical Antenna Installation on a Skin Panel	15
3.7	Preferred VOR Antenna Location for Maximum Signal Pickup With Minimum Ignition Interference	16
3.8	Typical Antenna Installation Involving a Cut Stringer	16
3.9	Typical Dipole Antenna Assembly	16
3.10	Typical VOR Antenna Balun	17
3.11	Coaxial Cable Preparation	17
3.12	Coaxial Cable Tinning Center Lead	17
3.13	Coaxial Cable Soldering Center Lead	17
3.14	Coaxial Cable Install Connector Body	18
3.15	Typical Wire Antenna Locations	18
3.16	Typical Marker Beacon Receiving Antenna	18
3.17	Typical Wing Tip Installations	19
3.18	Typical Fin Tip Installations	19
3.19	Typical Wire Antenna Installations	20
3.20	Preferred Position for Distance Measuring Antennas and/or ATC Radar Beacon Antennas	20
3.21	Typical ADF Antenna Installations	21
3.22	Typical Antenna Installation	22
3.23	Faying Surface Sealing	22
3.24	Fastener Sealing	22
3.25	Injection Sealing	23
3.26	Blade Antenna Installation	23
3.27	ATC Flush Mounted Antenna	23
3.28	Marker Beacon Flush Mounted Antenna	24
3.29	VOR Flush Mounted Antenna	24
4.1	Typical Anticollision or Supplementary Light Installation in a Skin Panel (Unpressurized)	26
4.2	Typical Anticollision or Supplementary Light Installation Involving a Cut Stringer (Unpressurized)	26
4.3	Typical Anticollision or Supplementary Light Installation in a Fin Tip	27
4.4	Typical Rotating Type Anticollision Light Installation for Pressurized Aircraft	27
4.5	Typical Oscillating Type Anticollision Light Installation for Pressurized Aircraft	27
4.6	Ramp Shadow Pattern	29
4.7	Conversion to Vertical vs. Horizontal Degrees	30
4.8	Conversion to True Square Degrees—1st Quadrant	30
4.9	Scale Drawings	31
4.10	Solid Angle Blockage—1st Quadrant	31
5.1	Typical Ski Installation	33
5.2	Typical Hub Installation	35
5.3	Typical Fuselage Fitting	36
5.4	Main Ski at Maximum Positive Incidence (Check Cable Tight)	37
5.5	Main Ski at Maximum Negative Incidence (Safety Cable Tight)	38
5.6	Main Ski Incidence Angles	38
5.7	Typical Nose Ski Installation	39
5.8	Typical Tail Ski Installation	40
6.1	Typical Oxygen Duration Table	46
6.2	Typical Floor Mounting	46
6.3	Typical Baggage Compartment Mounting	46

CONTENTS—Continued**LIST OF ILLUSTRATIONS—Continued**

<i>Figure</i>		<i>Page</i>
6.4	Typical Oxygen Installation in Light Twin Aircraft	47
7.1	Location of Cargo Release in Relation to the Rotorcraft's Center of Gravity	49
7.2	Cable Load Table	50
7.3	Typical Cargo Sling Wiring Diagram	51
7.4	Typical Cargo Sling Installation No. 1	52
7.5	Typical Cargo Sling Installation No. 1 (Showing Fuselage Attachment Fitting)	52
7.6	Typical Cargo Sling Installation No. 1 (Showing Fore and Aft Limiting Stops)	52
7.7	Typical Cargo Sling Installation No. 2 (Cargo Hook Attached Directly to Underside of Fuselage)	52
7.8	Typical Cargo Sling Installation No. 3 (4-leg, Cable Suspended)	53
7.9	Typical Cargo Sling Installation No. 3 (Showing Cable Sling Leg Attachment to Landing Gear Cross-Tube Fitting)	53
7.10	Typical Cargo Sling Installation No. 3 (Showing Cargo Sling in Stowed Position)	53
7.11	Typical Cargo Rack Installation No. 1	54
7.12	Typical Cargo Rack Installation No. 1 (Showing Attachment Detail)	54
7.13	Typical Cargo Rack Installation No. 2	55
7.14	Typical Cargo Rack Installation No. 2 (Showing Rack Partially Installed)	55
7.15	Typical Cargo Rack Installation No. 3	55
8.1	Glider Tow Angle	58
8.2	Banner Tow Angle	58
8.3	Typical Tow-Hitch Release Handle	59
8.4	Representative Steel Cable Qualities	60
* 8.5	Deleted Change 1	60
8.6	Tricycle Gear Aircraft	62
8.7	Conventional Gear Aircraft—Leaf Spring Type Tailwheel	62
8.8	Conventional Gear Aircraft—Shock Strut Type Tailwheel	63
8.9	Conventional Gear Aircraft—Tubular Spring Type Tailwheel	63
9.1	Single Diagonal Type Harness	66
9.2	Double Over-the-Shoulder Type Harness	66
9.3	Side Mounted—Single Diagonal Type Harness	67
9.4	Ceiling Mounted Inertia Reel—Single Diagonal Type Harness	68
9.5	Acceptable Mounting Area—Single Diagonal Type Harness	69
9.6	Ceiling Mounted Inertia Reel—Double Over-the-Shoulder Type Harness	69
9.7	Acceptable Mounting Areas—Double Over-the-Shoulder Type Harness	69
9.8	Floor Mounted Inertia Reel—Double Over-the-Shoulder Type Harness	71
9.9	Typical Floor Mounted Inertia Reel Installation	72
9.10	Typical Seat Mounted Inertia Reel Installation	72
9.11	Typical Bulkhead Reinforcement Installation	73
9.12	Typical Wing Carry—Through Member Installation	73
9.13	Typical Hat Section Reinforcement Installation	74
9.14	Typical Stringer Section Reinforcement Installation	74
9.15	Typical Stringer Section Reinforcement Installation	74
9.16	Typical Attachment to Tubular Members	75
10.1	Typical Battery Box Installation in Aft Fuselage Area	77
10.2	Typical Battery Box Installation in Aft Fuselage Area, Below Cabin Floorboards	77
10.3	Typical Battery Box Installation in Aft Fuselage Area	78
10.4	Typical Battery Box Installation Suspended From Cabin Floorboard Section	78
10.5	Battery with Integral Vent Nipples	79
10.6	Typical Battery Cutoff and Generator/Alternator Control Circuit	80
10.7	Change in Cantilever Support Battery Overhang Moment	82
11.1	Pressure Drop Data for Smooth Tubing	87

CONTENTS—Continued**LIST OF ILLUSTRATIONS—Continued**

<i>Figure</i>		<i>Page</i>
12.1	Extruded Track, Anchor Plates, and Associated Fittings	90
12.2	Miscellaneous Litter, Berth, and Cargo Tiedown Fittings	91
12.3	Typical Attachment of Fittings to Honeycomb Structures	92
12.4	Installation of Underfloor Support for Extruded Track	93
12.5	Typical Cargo Tiedown Straps and Cargo Nets	94
13.1	Sealant Application	98
13.2	Fair-lead Feed Through	99
13.3	Typical Connector	99
13.4	Coaxial Connectors	100

LIST OF TABLES

<i>Table</i>		<i>Page</i>
11.1	Instrument Air Consumption	86
11.2	Equivalent Straight Tube Line Drops for 90° Elbows	86
11.3	Differential Pressure Across Instrument Inlet and Outlet	86