

Illustrated Parts Catalog for 4-stroke aircraft engines type 912 and 914 Series, Rev. 4 of 01/2006 – **COMPLETE**

Single chapters:

- 1. Table of contents
- 2. <u>Introduction</u>
- 3. <u>List of the current pages</u>
- 4. <u>Table of amendments</u>
- 5. Crankcase, camshaft, hydraulic valve tappets
- 6. Crankshaft, piston, cylinder, sprag clutch
- 7. Cylinder head, valve cover, intake manifold
- 8. <u>Valve train</u>
- 9. <u>Ignition housing, water pump, rev. counter, electric starter</u>
- 10. <u>Magneto-generator, pick up, rectifier regulator</u>
- 11. <u>Double ignition coil assy, SMD-electronic module</u>
- 12. External alternator
- 13. External alternator single parts
- 14. <u>Electric-starter single parts</u>
- 15. Oil pump, oil filter, oil pressure sensor
- 16. Oil tank



- 17. Propeller gear assy
- 18. Overload clutch
- 19. Vacuum pump with drive
- 20. <u>Hydraulic governor arrangement for contant-speed</u> <u>propeller, governor</u>
- 21. <u>Fuel lines, carburetor, airbox, fuel pressure control</u> unit
- 22. Constant speed depression carburetor single parts
- 23. Water circuit, expansion tank
- 24. <u>Muffler, turbocharger, oil sump container</u>
- 25. <u>Turbocharger control unit</u>
- 26. Radiator, expansion tank, overflow bottle, cooling air baffle
- 27. Oil radiator
- 28. Engine suspension frame
- 29. Flydat, sensor set
- 30. Instruments, intake filter
- 31. Repair tools
- 32. <u>Lubricant, adhesives and sealing compound</u>
- 33. Gasket set, documentations
- 34. <u>Tightening torques</u>